



P3FOCMBOAGK
(WFOCMBOA_0004)

PartNo	Pos	Qty	Part description	Specification
105313705	-		set wiring	CMBOA
105313695	-		user manual	OVG340I
105313697	014		turning knob oven	
105313703	031		glass door oven complete	
105313696	034		door handle glass door oven	
407146652	037		hinge	CMBOA. 1 piece
105313701	039		door glass outer	
105313702	040		set door glass door handle	
105313698	041		door glass oven inner	
105313699	042		door safety fuse plate	INOX
407146557	056		gas thermostat	CMBOD
407146731	058		nozzle	D=0,52
407146564	080		burner complete	30 mbar
105313563	082		kit baking tray grid	
407146654	083		oven shelf	CMBOK
407146682	084		grid	CMBOK, 315x270mm
407144263	092		thermocouple	L=600mm
407146555	098		ignition cable	L=350mm
 105310498	104		ring glass cover rubber	
105313537	111		lamp complete	
105312415	113		button	
 105312648	114		ignition	2 burner
105313700	120		set Frame	CMBOA, RAL9006
407146651	170		kit support grid	1 piece, 4 fixations
105312836	175		thermostat	130°C, normally opfe
105313704	197		control panel oven	CMBOA