

ISOTTA

ULTRAFLEX ADAPTOR FOR SPORT PADDLES - p/n PADDLE UX ADP

Pic 1



- 1 Remove the 3 original screws on the Uflex tilt helm
- 2 Put adaptor p/n PADDLE UX ADP on. Face showed (pic 1) must stay toward the tilt helm , with small recession (pic 2) on the TOP of the tilt.
- 3 Use supplied Phillips screws to fit the adaptor on the Uflex tilt
- 4 (Pic 3) Screw Sport Paddles with the 3 screws M5x14 cylinder head screws (supplied with adapter).

Pic 2



Pic 3

